

---

How to use



DISKETTE

As of June 1983

You need the 80 MICRO issue that corresponds to the LOAD 80 disk:

- 1.) Read the RELOAD 80 column
- 2.) Check each program's Keybox. Make sure the program runs on your system!

LOAD 80 disks are double-sided. Simply flip the disk to use the other side.

The disk transfer system moves the files to your TRSDOS system or data disk as follows:

Insert the LOAD 80 disk in drive zero of your Model I or III. Press the reset button. After the computer boots the LOAD 80 disk, it will display the LOAD 80 logo for a moment, and then a list of programs on the disk will appear.

Single-drive users: When the computer prompts for the destination drive, press the zero key. The computer then tells you to mount the destination disk. Insert a TRSDOS disk.

---



---

## Single-drive users: (con't)

Swap the source and destination disks one time for each file transferred, and one more time to transfer the directory. The computer prompts you through the procedure, but be careful not to confuse your source and destination disks.

Two-drive users: Insert a TRSDOS disk in drive 1. This is the destination disk and drive. The computer transfers the files, reports on each file as it does, and tells you when it's finished.

If there is not enough space on the destination disk to transfer all files, the computer will offer to transfer only the files you specify. The computer won't transfer a file if there isn't enough room on the destination disk.

One final point: Because the new LOAD 80 disks contain both single and double-density tracks, you can't back-up this disk. However, once you've transferred the files, you can (and should) back-up the disk you've created.

For technical help with LOAD 80, please call or write to Amee Eisenberg, LOAD 80, 80 Pine Street, Peterborough, NH 03458. For all other problems, please call or write to Lori Eaton, 80 Pine Street, Peterborough, NH 03458.

